

STATUS: Finished / In-Progress

GameCube Mods and Repair

modding and repair of GameCube systems.



Items Needed

- Xeno-ModChip
- Laser assembly

Instructions

- Step 1
- Step 2

NOTES

Laser Eye Assembly always needs the potentiometer tweaked. Measure the resistance across the left leg and bottom right leg

LOWER Ohms = MORE LASER

Start with higher resistance and work your way down slowly.

200 to 500 Ohms is the average resistance. **DO NOT GO UNDER 175!!!**

- 001 GC laser needs resistance set between 450 - 600
- 101 GC laser needs resistance set between 150 - 250

Examples: Jon's old GC started at 216 and read at 196; Marc's newer GC started at 276 and read at 199

More Information

A youtube or 🌐 URL etc

From:

<https://home.woodchuckhunters.com/wiki/> - **DavWiki1**

Permanent link:

<https://home.woodchuckhunters.com/wiki/doku.php?id=projects:gamecube&rev=1739053809>

Last update: **2025/02/08 22:30**

